













Kod Code Bezeichnung	Ölçüler Dimensions Abmessungen								
	h h <sub>1</sub>	b	L	f	Uç Tipi Insert Type Plattentype	Altık Anvil Unterlage	Altık Vidası Anvil Screw Gewindehülse	Uç Vidası Insert Screw Plattenschraube	Torx Anahtar Torx Wrench Torx Schlüssel
SVJCR/L 12 12 F11	12	12	80	16	VC.....1103..	—	—	7815101	T08 IP
16 16 H11	16	16	100	20					
20 20 K11	20	20	125	25					
25 25 M11	25	25	150	32	VC.....1604..	7815002	7883102	7815102	T15 IP
20 20 K16	20	20	125	25					
25 25 M16	25	25	150	32					
32 25 P16	32	25	170	32					
25 25 M22	25	25	150	32	VC.....2205..	7815004	7883101	7883202	
32 25 P22	32	25	170	32					



Kod Code Bezeichnung	Ölçüler Dimensions Abmessungen								
	h h <sub>1</sub>	b	L	f	Uç Tipi Insert Type Plattentype	Altık Anvil Unterlage	Altık Vidası Anvil Screw Gewindehülse	Uç Vidası Insert Screw Plattenschraube	Torx Anahtar Torx Wrench Torx Schlüssel
SVZCR/L 12 12 F11	12	12	80	16	VC.....1103..	—	—	7815101	T08 IP
16 16 H11	16	16	100	20					
20 20 K11	20	20	125	25					
25 25 M11	25	25	150	32	VC.....1604..	7815002	7883102	7815102	T15 IP
20 20 K16	20	20	125	25					
25 25 M16	25	25	150	32					
32 25 P16	32	25	170	32					
25 25 M22	25	25	150	32	VC.....2205..	7815004	7883101	7883202	
32 25 P22	32	25	170	32					