













Kod Code Bezeichnung	Ölçüler Dimensions Abmessungen								
	h h <sub>1</sub>	b	L	f	Uç Tipi Insert Type Plattentype	Altık Anvil Unterlage	Altık Vidası Anvil Screw Gewindehülse	Uç Vidası Insert Screw Plattenschraube	Torx Anahtar Torx Wrench Torx Schlüssel
SDJCR/L 08 08 D07	8	8	60	8	DC....0702	—	—	7815101	T08 IP
10 10 E07	10	10	70	10					
12 12 F07	12	12	80	12					
16 16 H11	16	16	100	16	DC....11T3	7815000	7883102	7815102	T15 IP
20 20 K11	20	20	125	20					
25 25 M11	25	25	150	25					
32 25 P11	32	25	170	25					



Kod Code Bezeichnung	Ölçüler Dimensions Abmessungen								
	h h <sub>1</sub>	b	L	f	Uç Tipi Insert Type Plattentype	Altık Anvil Unterlage	Altık Vidası Anvil Screw Gewindehülse	Uç Vidası Insert Screw Plattenschraube	Torx Anahtar Torx Wrench Torx Schlüssel
SDHCR/L 08 08 D07	8	8	60	8	DC....0702	—	—	7815101	T08 IP
10 10 E07	10	10	70	10					
12 12 F07	12	12	80	12					
16 16 H11	16	16	100	16	DC....11T3	7815000	7883102	7815102	T15 IP
20 20 K11	20	20	125	20					
25 25 M11	25	25	150	25					
32 25 P11	32	25	170	25					